

All Zones
(On)

Turn Off

Zones 1-4

Change To Color
Buttons

Arrow Left
(Previous Color)

Arrow Right
(Next Color)

Arrow Up
(Brightness +)

Arrow Down
(Brightness -)

Music Sync

1. Full Color
2. Single Color Amplitude
3. Multi-Color Amplitude

Mode Change

1. Single Color Fade
2. Multi-Color Fade
3. Multi-Color Change
4. Strobe / Flash

